

Fitting Belt to New Style CB & CBD Conveyors

- Remove cover with bottom flap.
- Loosen both adjusting nuts that tension the belt.
- Once completely slack, remove idler roller from yoks and take out.
- Remove white under belt support roller.
- Remove plastic side guide rails from one side only.
- Remove bolts from leg fixing brackets on one side.
- Loosen the same two bolts on opposite side.
- Slide out old belt.
- Fit new belt in reverse.
- Any issues please contact the office.