



#### **AEC VCU / TCU FAILS TO GET UP TO TEMPERATURE**

This is normally as a result of the cooling solenoid valve stuck open and letting cold water in, the best solution is for the customer to remove solenoid valve, take it apart and clean it, the main reason the valve remains open is "dirt" under the diaphragm, so it cannot seat properly and shut off. If the operation is done and still a problem then could be solenoid valve coil needs replacing-burnt out.